

Engine Check

Event Open: 8 am – 5 pm*

*Event will shut down for a short lunch break



- **Remove everything from crankshaft**
 - CVT Primary
 - Keyways
 - Bolts
- **Disconnect throttle cable / linkage**
- **Idle engine to operating temperature**
- **Ensure kill switch operation**
- **Remove covers or tanks above governor linkage**
- **Tell us your requested idle RPM**
- **Tell us your requested max RPM**
 - Equal to or lower than 3800